



1

## Installation Guide




- ## 1. Hook installation

- ## 2. Trunnion installation

1. Remove the line cord protector firstly.
2. Wire locker end and hook, while make sure the locker end toward the hook to ensure water does not enter fixture.
3. Thread the hook onto the 3/4" NPT conduit until tight.
4. Tighten the M4X8 screw in the luminaire.
5. Using the sealing kits will ensure a watertight seal.



1. Remove the line cord protector firstly
2. Thread the led luminaire onto the 3/4" NPT conduit until tight , secure the M4X8 screw and make wire connections.
3. Caulk the conduit openings such as sealing kits, to ensure water does not enter fixture through 3/4 NPT conduit.
4. Silicone rubber is needed to ensure water does not enter fixture through 1/2" fitter.



### Wire Connection

The diagram shows a 6-core cable with the following color coding and functions:

| Color              | Function |
|--------------------|----------|
| Black              | Line     |
| White              | Neutral  |
| Green/Yellow Green | Ground   |
| Purple             |          |
| Gray               |          |
| (Unlabeled)        |          |

Note:Two dimming wire in the driver box

批准:

1

|       |       |
|-------|-------|
| 共 1 页 | 版本:A0 |
| 第 1 页 | 图纸:A4 |