



SAFETY WARNING - PLEASE READ CAREFULLY

WARNING - Be certain electrical power is OFF before and during installation and maintenance.

WARNING - Risk of fire and/or electric shock.

WARNING - Risk of fire or electric shock. For install by qualified electrician only. Do not attempt installation if not qualified.

WARNING - Verify that supply voltage is correct by comparing it with the luminaire label information.

WARNING - To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or other sharp objects. All wiring connections should be capped with UL approved wire connectors.

WARNING - Wear gloves and safety glasses at all times when removing luminaire from carton, installing, servicing or performing maintenance.

Retrofit Installation

1. Turn off all power before attempting installation.
2. Open the diffuser from the light fixture.
3. Remove the fluorescent tubes and ballast. Please dispose of fluorescent tubes properly as they contain mercury.
4. Connect the new wires as single-ended connection. Non-shunted G13 socket required. See Figure 1.
5. Insert LED T8 U-Bend into fixture.

